

< 40mm PomPom >

Exploded view diagram of the 40mm PomPom robot. The diagram shows numerous components labeled with numbers and names:

- Parts: 888, 885, 886, 887, 884, 881, 878, 879, 877, 876, 875, 874, 873, 872, 871, 869, 868, 867, 866, 865, 864, 863, 862, 858/867 Side View, G33, G34, G9, Brass 05, Brass 04, Brass 32 A+B+C, Brass 32 C, Brass 32 B, Brass 32 A, Brass 35, Brass 72, Brass 73, Brass 74, Brass 923, Brass 924, Brass 925, Brass 926, Brass 927, Brass 928.
- Instructions: "Remove" (indicated on parts 888 and the main body), "Cut" (indicated on parts 884, 881, 865, 864, 877, 876), and "90°" (indicated on various assembly points).
- Views: "881 Front View", "881 Top View" (with "Long" and "Short" variants), "873 Front View".

Assembly sequence for the 40mm PomPom robot:

- Top view showing the assembly of Brass 05 and Brass 04 onto the main body.
- Low-angle view showing the addition of Brass 32 C and Brass 32 B.
- High-angle view showing the addition of Brass 32 A.
- Low-angle view showing the addition of Brass 79.
- High-angle view showing the addition of Brass 78.

< 20mm Oerlikon >

Exploded view diagram of the 20mm Oerlikon robot. The diagram shows numerous components labeled with numbers and names:

- Parts: 924, 923, 925, Brass 72, Brass 73, Brass 926, Brass 927, Brass 928.
- Instructions: "90°" (indicated on various assembly points).
- Views: "923" and "924" views showing the internal mechanism.

Assembly sequence for the 20mm Oerlikon robot:

- Low-angle view showing the addition of Brass 79.
- High-angle view showing the addition of Brass 78.
- Assembly of Brass 72 and Brass 73.
- Assembly of Brass 926 and Brass 927.
- Assembly of Brass 928.
- Final assembly showing the robot's movement.